

CLEANING INSTRUCTIONS FOR ELOA - GLASS

Information

For proper and gentle cleaning for ELOA's high quality glass, we recommend following the cleaning instructions below so that you can enjoy the product for a long time - for the entire ELOA product range.

Make sure that the power is switched off during the entire time of cleaning! Secure the power against intrusion by third parties. The electrical parts must remain dry the entire time! Otherwise there is a risk of electric shock. Clean only the glass of the glass body with a safe distance to the electrical parts. Do not clean the glass near electrical parts! Do not spray glass cleaner or similar in the immediate vicinity of electrical parts!

Scope

For the entire ELOA range.

Cleaning instruction

Cleaning of the glass body from the outside:

- Proceed carefully and with steady hands during the entire cleaning process.
- Use glass cleaner or a mixture of warm water and detergent.
- Use a soft and clean cloth or a non-abrasive sponge.
- After drying, use a soft, dry cloth to remove water stains - this will preserve the clarity of the glass object.
- To remove limescale, use a concentrated amount of vinegar concentrate.

Glass color

- The color is incorporated into the glass and cannot be wiped off.

Information

- Do not turn the lamp in circles over 180° when cleaning, otherwise there is a risk of breaking the cable.